


Installation Instructions & Data Sheet

Indoor Space Light Level Sensor

Installation

1. Choose an accessible location for the sensor which is a good representation of the light conditions in the area to be monitored. Avoid locating the sensor where it will be subject to direct sunlight, strong artificial lighting or dark shadowed locations. Temperature must not exceed -25°C to $+70^{\circ}\text{C}$ or humidity 0% RH to 95% RH.
2. Fix the backplate to a wall or junction box using the knockout mounting holes.
3. Insert cable through one of the knockouts and connect as per diagram below.
4. Click the fascia to the backplate.

Wiring Details



Range :	ALS/2K	10 – 2000 Lux
Output :	4 – 20 mA	

No liability can be accepted for any errors or omissions in relation to the equipment and its application.
© Able Instruments & Controls Limited 2005. Reproduction by any means in whole or part is strictly forbidden without express written permission.